


Boiler Feed Pump

BOILER FEED PUMP



y: Distance between Motor Shaft and Pump Shaft

| Size | DNd | DNs | a | b | c1 | f | h1 | h2 | m1 | m2 | n1 | n2 | e1 | e2 | s1 | s2 | w | d | l | t | u |
|------|-----|-----|-----|----|----|-----|-----|-----|-----|----|-----|-----|-----|-----|----|----|-----|----|----|----|---|
| 3216 | 32 | 50 | 80 | 50 | 17 | 360 | 132 | 160 | 100 | 70 | 240 | 190 | 110 | 140 | 15 | 14 | 260 | 24 | 30 | 27 | 8 |
| 3220 | | | | | | | 160 | 180 | | | | | | | | | | | | | |
| 4016 | 40 | 65 | 100 | 65 | 17 | 360 | 132 | 160 | 100 | 70 | 240 | 190 | 110 | 140 | 15 | 14 | 260 | 24 | 30 | 27 | 8 |
| 4020 | | | | | | | 160 | 180 | | | | | | | | | | | | | |
| 5016 | 50 | 80 | 100 | 65 | 17 | 360 | 160 | 180 | 125 | 95 | 265 | 212 | 110 | 140 | 15 | 14 | 260 | 24 | 30 | 27 | 8 |
| 5020 | | | | | | | 200 | 280 | | | | | | | | | | | | | |
| 6516 | 65 | 100 | 125 | 65 | 17 | 360 | 180 | 225 | 125 | 95 | 320 | 250 | 110 | 140 | 15 | 14 | 260 | 24 | 30 | 27 | 8 |
| 6520 | | | | | | | 225 | 280 | | | | | | | | | | | | | |
| 8016 | 80 | 125 | 125 | 65 | 17 | 360 | 180 | 225 | 125 | 95 | 320 | 250 | 110 | 140 | 15 | 14 | 260 | 24 | 30 | 27 | 8 |

Ask SCARDANA about all pump replacements

SCARDANA®

DIVISION OF SCARDANA CORPORATION

Toll free Fax : (1) - 877 - 228 - 9879

FAX: (1) - 450 - 671 - 3898

TEL: (1) - 450 - 465 - 2480

E-mail : sales@scardana.com

Web : www.scardana.com